



Cameras and OpenCV

Mckenzie Mack
GenCyber Workshop



Agenda



- Camera Introduction
- Camera Setup
- OpenCV
- Basic Functions of OpenCV




Learning Objectives

- Describe how to attach and set up a camera to take photos and videos with the Raspberry Pi
- Explore the many uses of OpenCV
- Explain how to use simple functions included in the OpenCV library to load and view an image or video


Camera Introduction

- Add-on components can be used along with the Raspberry Pi to enhance its capabilities
 - LED screens
 - motion sensors
 - cameras
- When combined with Python scripts, the Arducam Auto Focus Camera can be used to capture both photos and videos



Camera Setup

- To install the camera:
 - Lift the black tab next to the A/V port
 - Insert the camera ribbon into the opening
 - **be sure the blue side is facing the USB ports**
 - press down evenly on the tabs to secure the ribbon in place



Camera Setup

- From there, use **sudo raspi-config** to access the Pi Software Configuration Tool
 - Choose Option 3, then P1 to enable connection to the camera
 - Reboot the computer
- The camera can now be used to take pictures and videos through the command line or through a Python script

```
Raspberry Pi Software Configuration Tool (raspi-config)

P1 Camera      Enable/disable connection to the Raspberry Pi Camera
P2 SSH         Enable/disable remote command line access using SSH
P3 VNC         Enable/disable graphical remote access using RealVNC
P4 SPI         Enable/disable automatic loading of SPI kernel module
P5 I2C         Enable/disable automatic loading of I2C kernel module
P6 Serial Port Enable/disable shell messages on the serial connection
P7 1-Wire      Enable/disable one-wire interface
P8 Remote GPIO Enable/disable remote access to GPIO pins

<Select>      <Back>
```



Image Capture

- A simple way to capture an image using Python is by utilizing the **PiCamera** package

```
1 from picamera import PiCamera
2 import time
3
4 camera = PiCamera()           #creates camera object to control camera
5
6 camera.start_preview()        #starts camera preview before image capture
7 time.sleep(2)                 #tells camera to wait 2 seconds before capturing picture
8
9 camera.capture("newPhoto.jpg") #camera takes picture and saves it as newPhoto.jpg
10
11 camera.stop_preview()         #stops camera preview
```





Video Capture

- Videos can be captured in a similar way:

```
1 from picamera import PiCamera      #imports PiCamera package
2 import time                        #imports time package
3
4 camera = PiCamera()                #creates camera object to control camera
5
6 camera.start_preview()              #starts camera preview before video capture
7 camera.start_recording("Desktop/newVid2.h264") #starts recording video and saves
8                                     #it as newVid2.h264 on the Desktop
9 time.sleep(10)                     #tells program to wait 10 seconds before
10                                   #executing next line
11 camera.stop_recording()             #stops video recording
12 camera.stop_preview()              #stops camera preview
```


OpenCV

- These images and videos can then be analyzed using **OpenCV**
 - OpenCV: library of functions aimed at automating tasks that the human visual system performs
 - applications of OpenCV include:
 - image filtering
 - facial detection
 - facial recognition
 - motion tracking
 - object recognition
 - and many more!





Basic Functions of OpenCV

- **imread()** can be used to load an image from a specific file
 - format: **cv2.imread(*path to file, flag for color*)**
 - flags for color include:
 - color (any transparency is ignored): 1
 - grayscale: 0
 - unchanged: -1
- To resize the image, **resize()** can be used
 - format: **cv2.resize(*image, (width in pixels, height in pixels)*)**
 - to resize by a certain scale: **cv2.resize(*file path, (0,0), fx = scale to resize x-axis, fy = scale to resize y-axis*)**
 - ex: **newImg = cv2.resize("Desktop/me.jpeg", (0,0), fx = 0.75, fy = 0.75)**
^resizes image to $\frac{3}{4}$ its original size



Basic Functions of OpenCV

- Once the image has been loaded, any changes made to the image can be saved using **imwrite()**
 - format: **cv2.imwrite(*path to output file, modified source image*)**

```
import cv2

# read image as grey scale
grey_img = cv2.imread('/home/img/python.png', cv2.IMREAD_GRAYSCALE)

# save image
status = cv2.imwrite('/home/img/python_grey.png', grey_img)

print("Image written to file-system : ", status)
```



Basic Functions of OpenCV

- After the filters or modifications have been saved, **imshow()** can be used to show the image to the user
 - format: **cv2.imshow(*title of window*, *image*)**
 - **cv2.waitKey(0)** shows the image to the user an infinite amount of time until the user hits any key on the keyboard
 - **cv2.destroyAllWindows()** closes the window that holds the

```
cv2.imshow( 'Image' , source)  
cv2.waitKey(0)  
cv2.destroyAllWindows()
```



Basic Functions of OpenCV

- Viewing videos using OpenCV is a little more complicated
 - **VideoCapture()** is used to load the video
 - format: **cv2.VideoCapture(*file path*)**
 - **release()** is used to close the video
 - instead of displaying the entire video at once, the video is displayed on a frame-by-frame basis
 - You will look at how to code this in the lab!

```
source = cv2.VideoCapture("Desktop/newVid.h264")  
  
source.release()  
cv2.destroyAllWindows()
```



Resources

- <https://www.youtube.com/watch?v=nx8gDSS1vO4>
- <https://opencv.org/>
- <https://www.tutorialkart.com/opencv/python/opencv-python-save-image-example/>
- <https://www.youtube.com/watch?v=snMNI5dplc>



LAB



complete the questions for the lab - Images, Filters, and Cybersecurity